

URBTRACK U116

Tecnologia: 2G

Servidores

 SP: 49.12.92.6 - dns.mine.nu | Porta = 6023

 AL: 168.119.25.88 - ese.mine.nu | Porta = 5023

 SC: 167.235.35.219 - sc.mine.nu | Porta = 5023

 PI: 167.235.34.85 - dns.alfarastreamento.com | Porta = 5023

 SP Sorocaba: 65.21.232.27 - sastracker.mine.nu | Porta = 6023

 MA: 65.21.249.189 - telensat.mine.nu | Porta = 5023

Comandos

Porta(s): 5023 ou 6023

Configuração Inicial

Comando 1: server,36977858,1.dns.mine.nu,5023# **(Comando para conexão do rastreador na plataforma)**

O IP/DNS devem ser substituídos de acordo com o servidor!

Comando 2: apn,smart.m2m.vivo.com.br,vivo,vivo# **(Ex: Apn da Vivo)**

Necessário alterar o comando de acordo com a APN utilizada

Comando 3: gmt,w,0# **(Configuração do fuso horário)**

Comando 4: timer,60# **(Tempo de transmissão em movimento)**

Comando 5: static,1# **(Tempo de transmissão parado)**